

Manual, Assembly instruction: Brodit 852367

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thick end of the enclosed gap openers into the gap between the dashboard overhang and the dashboard center panel, to widen the gap. Press forward on the right side of the air vent. Peel off the cover of adhesive tape on the ProClip.

2. Press the left side of angled edge on the upper part of the ProClip into the gap next to the left gap opener. Press until you see or hear/feel it clicks into place. Press firmly forward on the right upper part of the ProClip so the rest of the angled edge goes into the gap next to the right gap opener. Press until you see or hear/feel it clicks into place.

3. Press firmly forward on the lower right side of the ProClip so the grooved edges snap over the narrow panel section by the air vent. Press until you see or hear/feel it clicks into place. Adjust the air vent and pull out the gap openers.

4. The ProClip is in place.