

Manual, Assembly instruction: Brodit 852382

Center mount, ONLY in Canada

1.)



2.)



3.)



4.)



Peel off the cover of the adhesive tape on the ProClip.

1. Press the curved edge on the lower part of the ProClip into the gap between the stereo and the surrounding panel frame.

2. Flip the ProClip upwards and forward towards the air vent and lift it over the front part of the dashboard.

3. Press down on top of the ProClip for best possible attachment of the adhesive tape.

4. The ProClip in place