

Manual, Assembly instruction: Brodit 852403

Center mount



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the air vent and the dashboard to widen the gap.

2. Press the grooved edge on the lower part of the ProClip into the gap between the air vent and the padded part of the dashboard to the left of the wheel for adjusting the vent. Press the ProClip half way of the thin part into the gap.

3. Press the grooved edge on the upper part of the ProClip upwards and forward so it goes into the gap between the gap openers. Press the ProClip half way of the thin part into the gap. Press forward on the lower part of the ProClip so the rest of the thin area goes all the way into the gap. Then press forward on the upper part of the ProClip so the rest of the thin area goes all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.