

## Manual, Assembly instruction: Brodit 852412

Angled mount

1.)



2.)



3.)



4.)



**Attention! Read all instructions before attaching the ProClip.** This ProClip consists of two parts. Part 1. Attaching piece. Part 2. ProClip faceplate.

**1.** Clean the surface between the control panel and the dashboard with the enclosed alcohol pad. Press the thin ends of the enclosed gap openers into the gap between the control panel and the dashboard, to widen the gap. Place the gap openers about 10 cm apart. Press Part 1 into the gap between the gap openers.

**2.** Press alternatly on the upper and the lower part of the attaching piece until it is all the way in the gap. Pull out the gap openers.

**3.** Peel off the cover of the adhesive tape on Part 2. Place Part 2 so the holes match over the holes in Part 1. Use the enclosed screws to screw Part 2 onto Part 1. Screw straight into Part 1, in the same angle as Part 1.

**4.** The ProClip in place.