

Manual, Assembly instruction: Brodit 852426

Center mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip. Note: This ProClip can be attached within the width of the air vent.

1. Peel off both adhesive tape covers on the ProClip. Choose location for the ProClip within the range of the width of the air vent. Place the ProClip over the air vent at the selected position. Press the thin end of the two enclosed gap openers into the gap, one on each side of the ProClip, between the padded part of the dashboard and the center console panel to widen the gap.

2. Press the thin end of the lower part of the ProClip all the way into the gap between the gap openers. Pull out the gap openers.

3. Press the grooved edge on the upper part of the ProClip into the gap between the air vent frame and the padded dashboard. Press until you see or hear/feel it snaps into place. (Note: if the gap is very tight, press the thin end of the two enclosed gap openers into the gap, one on each side of the ProClip, to widen the gap. Then press the ProClip into the gap)

4. The ProClip is in place.