

## Manual, Assembly instruction: Brodit 852447

Center mount

1.)



2.)



3.)



4.)



1. Press the curved edge on the lower part of the ProClip into the gap between the climate control panel and the surrounding panel frame.

2. Press forward on the upper part of the ProClip so the grooved edge goes into the gap between the panel frame and the padded dashboard. Press until you see or hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.