

Manual, Assembly instruction: Brodit 852459

Center mount

1.)



2.)



3.)



4.)



1. Press the thin end of the enclosed gap opener into the gap between the stereo and the surrounding panel frame to widen the gap.

2. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener and slide the ProClip to the left.

3. Press forward on the upper part of the ProClip so the grooved edge snaps into the gap between the panel frame and the padded dashboard. Press until you see or hear/feel it snaps into place.

4. The ProClip in place.