

Manual, Assembly instruction: Brodit 852467

Center mount



Attention! Read all instructions before attaching the ProClip

1. Press the lower part of the ProClip, with angle, into the gap between the airvent and the panel frame at pos. 1.
2. Press the upper part of the ProClip, with groove, into the gap between the air vent and the padded dashboard at pos. 2.