

Manual, Assembly instruction: Brodit 852473

Angled mount

1.)



2.)



3.)



4.)



Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the right side of the ProClip into the gap between the console edge and the console sidewall.
2. Place your fingers on both hands behind the ProClip faceplate. Pull the ProClip towards you and leftwards, towards the stereo, so the angled edge on the left side of the ProClip hooks over the console edge.
3. Press on the left side of the ProClip, towards the console edge, so the adhesive on the ProClip attaches properly.
4. The ProClip is in place.