

Manual, Assembly instruction: Brodit 852478

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip. Peel off the cover of the adhesive tape on the ProClip.

1. Press the angled edge on the upper part of the ProClip into the gap between the panel frame and the padded dashboard ledge.

2. Flip the ProClip downwards so the angled edge hooks under/behind the panel frame.

3. Press forward on the lower part of the ProClip so the grooved edge on vertical part of the ProClip goes into the gap between the panel surrounding the climate control and the center console. Press until you see or hear/feel it snaps into place.

4. The ProClip is in place.