

Manual, Assembly instruction: Brodit 852495

Angled mount

1.)



2.)



3.)



4.)



Clean the surface with the enclosed alcohol pad. Peel off the cover on the adhesive tape on the ProClip.

1. Place the angled edge on the left side of the ProClip over the console edge.

2. Press forward on the right side of the ProClip so the angled edge on the right side snaps/hooks over the edge in the console wall. Feel to make sure the angled edge is hooked all the way over console edge.

3. The ProClip is in place.

4. The ProClip is in place.