

Manual, Assembly instruction: Brodit 852505

Center mount

1.)



2.)



3.)



4.)



Peel off the cover of the adhesive tape on the ProClip. Open the compartment box on the dashboard.

1. Press the grooved edge on the lower part of the ProClip into the gap between the air vent panel frame and the buttons below.

2. Press forward on the upper part of the ProClip so the part with adhesive tape attaches to the air vent ledge. Press down on top of the ProClip for best possible attachment. Close the compartment box. If some of the gaps it too tight, press the thin end of the enclosed gap opener into the gap to widen it.

3. The ProClip in place.