

Manual, Assembly instruction: Brodit 852506

Angled mount

1.)



2.)



3.)



4.)



Open the glove compartment.

1. Press/hook the angled edge on the right side of the ProClip into the gap between the dashboard and the glove compartment frame and flip the ProClip to the left so the angled edge hooks behind the glove compartment frame.

2. Pull the left side of the ProClip over the console frame edge and push the edge into the gap between the center panel and the padded console edge. Close the glove compartment.

3. The ProClip is in place.

4. The ProClip is in place.