

Manual, Assembly instruction: Brodit 852511

Angled mount



Attention! Read all instructions before attaching the ProClip

1. Clean the surface at pos. 1. and 2. with the enclosed alcohol pad. Peel off both adhesive tape covers on the ProClip.
2. Press the left part of the ProClip into the gap between the center console panel and the padded dashboard at pos. 1.
3. Hook the right part of the ProClip over the console frame and press it into the gap between the panel frame and the padded dashboard at pos. 2.
4. The ProClip is in place.