

Manual, Assembly instruction: Brodit 852523

Center mount



Peel off the cover of the adhesive tape on the ProClip.

1. Press/hook the angled edge on the upper part of the ProClip into the gap between the panel frame and the padded dashboard.

2. Press the grooved edge on the lower part of the ProClip into the gap between the air vent panel frame and the padded part of the dashboard. Press until you see or hear/feel it snaps into place.

3. The ProClip is in place.

4. The ProClip is in place.