

Manual, Assembly instruction: Brodit 852526

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the air vents to widen the gap.
2. Press the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap between the dashboard and the frame surrounding the control panel below the air vents. Pull out the gap opener.
4. The ProClip is in place.