

Manual, Assembly instruction: Brodit 852540

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the climate control panel and the air vent frame to widen the gap.
2. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.
3. Press the gap opener into the gap between the padded dashboard and the air vent frame. Then press the grooved edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.