

Manual, Assembly instruction: Brodit 852544

Center mount



Attention! Read all instructions before attaching the ProClip

1. Press the thin end of the enclosed gap opener into the gap between the climate control panel and the surrounding panel frame to widen the gap. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. You can attach the ProClip further in the position it is now, or slide it to the left for even better positioning as shown in the picture

3. Press forward on the upper part of the ProClip so the grooved edge goes into the gap between the air vent panel and the padded dashboard. Press until you see or hear/feel it snaps into place.

4. The ProClip in place