

Manual, Assembly instruction: Brodit 852549

Center mount



Peel off the cover of adhesive tape on the ProClip.

1. Place the angled edge on the lower part of the ProClip onto the climate control wheel. Press firmly forward on the lower part of the ProClip and slide the angled edge up into the gap between the climate control wheel and the surrounding panel frame.
2. Press the thin end of the enclosed gap opener into the gap between the panel frame and the padded dashboard, next to the ProClip, to widen the gap.
3. Press down on top of the ProClip so the angled edge goes into the gap next to the gap opener.
4. The ProClip in place.