

Manual, Assembly instruction: Brodit 852551

Center mount



1. Press the enclosed Gap opener into the gap between the climate control panel and the surrounding panel frame to widen the gap.

2. Press the part of the ProClip with curved edge into the gap next to the Gap opener and slide the ProClip to the left. Pull out the Gap opener.

3. Press the enclosed Gap opener into the gap between the padded dashboard and the panel frame to widen the gap, and then push forward on the upper part of the ProClip so the angled edge snaps into the gap next to the Gap opener. Note: If the angled edge doesn't snap into place, place your fingers on top of the edge and press down so it snaps in. Pull out the Gap opener.

4. The ProClip in place.