

Manual, Assembly instruction: Brodit 852563

Center mount



Attention! Read all instructions before attaching the ProClip.

1. Clean the surface at pos. 1 with the enclosed alcohol pad. Peel off the adhesive tape cover on the ProClip.
2. Press the enclosed gap opener into the gap between the air vent frame and the padded dashboard at pos.2. to widen the gap.
3. Press the angled edge on the lower part of the ProClip, with adhesive tape, into the gap between the console frame and the air vent frame at pos.1.
4. Push the upper part of the ProClip forward and press the angled edge into the gap next to the gap opener at pos.2. Press firmly until you hear/feel it snap into place.