

Manual, Assembly instruction: Brodit 852597

Center mount



Attention! Read all instructions before attaching the ProClip Clean the surface with the enclosed alcohol pad.

1. Press the enclosed gap openers into the gap to widen the gap between the dashboard and the frame surrounding the instrument panel. Peel off the adhesive tape cover on the ProClip.

2. Press the right part of the ProClip, with adhesive tape, into the gap at between the control panel and the padded dashboard. Align the ProClip with the air vent.

3. Press the left part of the ProClip, with groove, into the gap between the both gap openers. Press forward and away from the steering wheel so the ProClip snaps into place. Pull out the gap openers.

4. ProClip in place.