

Manual, Assembly instruction: Brodit 852598

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard, to widen the gap. Open the glove compartment. Press the curved edge on the left part of the ProClip into the gap below the gap opener.

2. Flip the ProClip rightward/forward so the left curved edge hooks under the frame surrounding the control panel. Pull out the gap opener.

3. Press the gap opener into the gap between the glove compartment and the dashboard and hold it in the gap. Press the right part of the ProClip leftward, toward the center console sidewall. Then press forward/upward so the grooved edge goes into the gap below the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener. Close the glove compartment.

4. The ProClip is in place.