

Manual, Assembly instruction: Brodit 852599

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the padded dashboard to widen the gap. Use the enclosed alcohol pad to clean the surface on the dashboard where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.

2. Press/Hook the angled edge on the lower part of the ProClip into the gap between the air vent frame and the panel above the stereo. Slide the ProClip to the left.

3. Flip the ProClip upwards and press forward on the upper part of the ProClip so it snaps into the gap next to the gap opener. Note: If the angled edge won't snap into the gap, press down on top of the ProClip until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip in place.