

Manual, Assembly instruction: Brodit 852610

Angled mount

1.)



2.)



3.)



4.)



1. Press the enclosed gap opener into the gap between the center panel frame and the padded console edge (right below the ProClip as shown in picture) to widen the gap.

2. Peel off the cover of the adhesive tape on the ProClip and press the lower part of the grooved edge of the ProClip into the gap right above the gap opener. Then press forward on the top part of the ProClip so the rest of the grooved edge snaps into the gap. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

3. The ProClip in place.