

Manual, Assembly instruction: Brodit 852619

Angled mount

1.)



2.)



3.)



4.)



Peel off the cover of the adhesive tape on the ProClip.

1. Place the ProClip over the center dash console edge and hook the angled edge on the left side of the ProClip into the gap between the stereo and the surrounding panel frame.

2. Press forward on the right side of the ProClip so the angled edge snaps into the gap in the console wall.

3. The ProClip is in place.

4. The ProClip is in place.