

Manual, Assembly instruction: Brodit 852620

Center mount

1.)



2.)



3.)



4.)



1. Press the grooved edge on the upper part of the ProClip into the gap between the air vent frame and the padded dashboard at pos.1. Press until you see or hear/feel it snaps into place

2. Press the lower thin part of the ProClip into the gap between the padded part of the dashboard and the narrow wood grain panel at pos. 2.

3. The ProClip is in place.

4. The ProClip is in place.