Manual, Assembly instruction: Brodit 852628

Angled mount

1.)

2.)

3.)

4.)

Attention! Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Clean the surface on the console side wall and between the climat control panel and the console edge with the enclosed alcohol pad. Peel off the cover of the adhesive tape on the ProClip. Hook the angled edge on the right side of the ProClip over the console sidewall edge.

2. Place your fingers behind the faceplate and pull the ProClip towards you. (You will feel a firm tension in the ProClip)

3. Hook the angled edge on the ProClip over the console edge and into the gap between the climate control panel and the console edge.

4. The ProClip in place.