

Manual, Assembly instruction: Brodit 852649

Angled mount. Only for models with AC.

1.)



2.)



3.)



4.)



Attention: This ProClip consists of two parts. Part 1: Attaching piece Part 2: ProClip faceplate

1. Peel off the cover of the adhesive tape on Part 1 and press the angled edge of Part 1. into the gap between the center console panel and the padded console edge.

2. Push forward on the right side of Part 1. towards the padded console edge, so the angled edge of Part 1. hooks under/behind the panel frame and the adhesive sticks to the console edge.

3. Peel off the cover of the adhesive tape on Part 2 and place it onto Part 1. so the holes match up and the adhesive tape on Part 2 is on the left side attaching to the center console panel. Screw the enclosed screws into the holes in Part 2.

4. The ProClip is in place.