

Manual, Assembly instruction: Brodit 852650

Center mount

1.)



2.)



3.)



4.)



1. Peel off the cover of the adhesive tape on the ProClip and place the ProClip over the gap between the dashboard panel and the padded dashboard edge.

2. Press forward on the left side of the ProClip so the grooved edge goes into the gap. Press until you see or hear/feel it snap into place.

3. Push forward on the right side of the ProClip so the grooved edge snaps into the gap between the panel frame surrounding the stereo and the padded dashboard edge. Press until you see or hear/feel it snap into place. The ProClip is in place.