

Manual, Assembly instruction: Brodit 852658

Angled mount

1.)



2.)



3.)



4.)



1. Place the lower corner of the ProClip into the gap between the console frame surrounding the stereo and the padded console edge.

2. Press the ProClip into the gap and at the same time adjust the horizontal arm on the left side of the ProClip to be placed over the gap between the console frame surrounding the stereo and the dashboard.

3. Press the horizontal arm of the ProClip into the gap between the console frame surrounding the stereo and the dashboard. Press until you see or hear/feel it snaps into place.

4. The ProClip in place.