

Manual, Assembly instruction: Brodit 852667

Center mount

1.)



2.)



3.)



4.)



Peel off the cover on the adhesive tape on the ProClip.

1. Press the angled edge on the upper part of the ProClip into the gap between the instrument panel frame and the padded dashboard. Flip the ProClip downwards so the angled edge hooks behind the panel.

2. Place the ProClip into the gap between the padded dashboard and the stereo panel frame.

3. Press firmly forward on the lower part of the ProClip so the angled edge snaps/hooks behind the stereo panel frame. Press until you see or hear/feel it snaps into place.

4. The ProClip in place.