

Manual, Assembly instruction: Brodit 852673

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Adjust the air vent upwards. Clean the surface at pos. 2 with the enclosed alcohol pad. Peel off the cover of the adhesive tape on the ProClip.
2. Press the upper part of the ProClip, with angle, into the gap at pos. 1.
3. Hook the lower part of the ProClip, with adhesive tape, over the edge of the air vent frame at pos. 2. Adjust the air vent downwards.