

Manual, Assembly instruction: Brodit 852675

Angled mount



Attention! Read all instructions before attaching the ProClip

1. Clean the surface at pos. 1 and pos. 2 with the enclosed alcohol pad. Peel off both adhesive tape covers on the ProClip.
2. Press the lower part of the ProClip into the gap at pos. 1 between the console and the dashboard. Press until you hear or see/feel it snap into place.
3. Pull the ProClip towards the steering wheel. Press the left part of the ProClip into the gap at pos 2 between the control panel and the surrounding frame.