

Manual, Assembly instruction: Brodit 852676

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Clean the surface with the enclosed alcohol pad. Peel off the adhesive tape cover on the ProClip.
2. Place the ProClip over the padded part.
3. Press down on top of the ProClip towards the floor until the angled edge on the left side of the ProClip is under the padded edge.
4. The ProClip is in place.