

Manual, Assembly instruction: Brodit 852683

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Open the glovecompartment. Open the radiohatch on the control panel. Clean the surface at pos. 1 and pos. 2 with the enclosed alcohol pad. Peel off three adhesive tape covers on the ProClip.
2. Hook the short left part of the ProClip over the edge of the padded dashboard at pos. 1.
3. Press the right part of the ProClip, with groove, into the gap at pos. 2 between the padded dashboard and the glovecompartment.