

Manual, Assembly instruction: Brodit 852686

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Clean the surface at pos. 1 and pos. 2 with the enclosed alcohol pad. Place a screwdriver into the gap at pos.1 between the control panel and the padded dashboard. Pry the frame surrounding the control panel loose a bit.
2. Peel off the cover of the adhesive tape on the ProClip fixingplate. Press the fixingplate, with groove, into the gap below the screwdriver. Pull out the screwdriver.
3. Peel off both adhesive tape covers on the ProClip face plate. Place the holes in the faceplate over the holes in the fixingplate. Fasten it by using the enclosed screws.