

Manual, Assembly instruction: Brodit 852689

Angled mount ONLY for models with extra equipment.



Attention! Read all instructions before attaching the ProClip

1. Loosen the screw at pos. x. Peel off both adhesive tape covers on the ProClip.
2. Press the grooved part of the ProClip into the gap at pos. 1 between the upper and the lower part of the control panel. Press forward on the ProClip until you see or hear/feel it snap into place.
3. Screw on the screw.