

Manual, Assembly instruction: Brodit 852692

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the panel frame and the padded part of the dashboard to widen the gap.
2. Place the grooved edge on the upper part of the ProClip over the panel frame edge in the air vent.
3. At the same time: press the down and forward on the lower part of the ProClip so the grooved edge goes into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip in place.