

Manual, Assembly instruction: Brodit 852698

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Open the glove compartment. Clean the surface at pos. 1 and pos. 2 with the enclosed alcohol pad. Peel off both adhesive tape covers on the ProClip.

2. Press the left part of the ProClip into the gap at pos. 1 between the stereo and the surrounding frame.

3. Hook the long right part of the ProClip over the edge by the glove compartment at pos. 2. Close the glove compartment.