

Manual, Assembly instruction: Brodit 852699

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Clean the surface at pos. 2 with the enclosed alcohol pad. Peel off the cover of the adhesive tape on the ProClip.
2. Press the left part of the ProClip, with angle, into the gap between the control panel and the frame surrounding the stereo at pos. 1.
3. Press forwards on the ProClip so the right part of the ProClip, with adhesive tape, hooks over the edge of the control panel at pos. 2.