

Manual, Assembly instruction: Brodit 852700

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Press the upper part of the ProClip, with angle, into the gap at pos. 1 between the panel and the padded dashboard.
2. Press the lower part of the ProClip, with groove, into the gap at pos. 2 between the frame surrounding the control panel and the padded dashboard.