

Manual, Assembly instruction: Brodit 852712

Angled mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Press the thin end of the enclosed gap opener into the gap at pos. 1 to widen the gap between the center console and the dashboard.
2. Press the long right part of the ProClip into the gap below the gap opener at pos. 1. Place the ProClip above the gap at pos. X. Pull out the gap opener.
3. Press the gap opener into the gap at pos. 2 between the frame surrounding the control panel and the dashboard. Align the gap opener with the lower part of the stereo. Press the short left part of the ProClip into the gap below the gap opener at pos. 2. Pull out the gap opener.