

Manual, Assembly instruction: Brodit 852713

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Clean the surface at pos. 1 and pos. 2 with the enclosed alcohol pad. Peel off both adhesive tape covers on the ProClip.
2. Hook the upper part of the ProClip, with angle, into the gap at pos. 1 between the frame surrounding the air vent and the dashboard.
3. Hook the lower part of the ProClip under the lower part of the air vent at pos. 2.