

Manual, Assembly instruction: Brodit 852714

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of the adhesive tape on the ProClip. Press the angled edge on the upper part of the ProClip into the gap at between the dashboard and the frame surrounding the air vents.

2. Press forward on the ProClip so the angled upper edge hooks into the gap.

3. Press leftward on the ProClip so the grooved edge on the left part goes into the gap between the dashboard and the frame surrounding the control panel. Press forward on the ProClip so the adhesive tape attaches to the dashboard.

4. The ProClip is in place.