

Manual, Assembly instruction: Brodit 852719

Center mount Mégane: NOT models with factory navigation.

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Press the thin end of the enclosed gap opener into the gap at pos. 1 to widen the gap between the coin shelf and the dashboard. Peel off both adhesive tape covers on the ProClip,
2. Press the upper part of the ProClip, with groove, into the gap at pos. 1. Pull out the gap opener.
3. Press the lower part of the ProClip into the gap at pos. 2 between the panel surrounding the air vent and the control panel.