

Manual, Assembly instruction: Brodit 852721

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Press the thin end of the enclosed gap opener into the gap to widen the gap between the panel surrounding the air vent and the panel surrounding the control panel. Peel off the cover of the adhesive tape on the ProClip.
2. Press the lower part of the ProClip, with adhesive tape, into the gap next to the gap opener. Pull out the gap opener.
3. Press the upper part of the ProClip into the gap between the panel surrounding the air vent and the dashboard overhang.