

Manual, Assembly instruction: Brodit 852723

Center mount

1.)



2.)



3.)



4.)



Attention! Read all instructions before attaching the ProClip

1. Press the thin end of the enclosed gap opener into the gap at pos. 1 to widen the gap. Clean the surface at pos. 1 and pos. 2 with the enclosed alcohol pad. Peel off both adhesive tape covers on the ProClip.
2. Press the lower part of the ProClip, with curve, into the gap next to the gap opener at pos. 1.
3. Press the upper part of the ProClip, with angle, into the gap at pos. 2. Slide the ProClip sideways into desired position.