

Manual, Assembly instruction: Brodit 852748

Center mount



Attention! Read all instructions before attaching the ProClip

1.Press the thin end of the enclosed gap opener into the gap between the control panel and the frame surrounding the air vents, to widen the gap. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press forward on the ProClip so the angled edge on the upper part of the ProClip hooks into the gap between the dashboard and the frame surrounding the air vents.

3. The ProClip is in place.

4. The ProClip is in place.