

Manual, Assembly instruction: Brodit 852755

Center mount



Attention! Read all instructions before attaching the ProClip

1. Press the thin end of the enclosed gap opener into the gap at pos. 2 to widen the gap between the dashboard and the frame surrounding the control panel. Clean the surface at pos. 1 with the enclosed alcohol pad. Peel off the cover of the adhesive tape on the ProClip.
2. Press the upper part of the ProClip, with adhesive tape, into the gap at pos. 1 between the dashboard and the frame surrounding the air vents.
3. Press the lower part of the ProClip into the gap and towards yourself so it snaps into the gap next to the gap opener at pos. 2. Pull out the gap opener.